



Signs must be placed at the base of the crane tower to warn that unauthorised personnel are not permitted on the crane. The signs should be in red on a white background with a no access symbol and the wording *“No Admittance Authorised Personnel Only”*. An example of a commercially available sign (Easy Fix 400mm x 300mm) is as follows :-



Signs should also be placed at the top of the tower below the slew ring to warn of the hazards associated with passing through the slewing section when the crane is in use. The signs should be in black on a yellow background with a triangular warning symbol and the wording *“Warning, Hazardous area. Do not pass through the slewing section until given permission by the crane operator”*. An example of a commercially available sign with additional wording added is as follows :-

